

HONDAXR 250 R (ME06)	250	1995
HONDAXR 250 R (ME06)	250	1994
HONDAXR 250 R (ME06)	250	1993
HONDAXR 250 R (ME06)	250	1992
HONDAXR 250 R (ME06)	250	1991
HONDAXR 250 R (ME06)	250	1990
HONDAXR 250 R (ME06)	250	1989
HONDAXR 250 R (ME06)	250	1988
HONDAXR 600 R (PE04)600		1998
HONDAXR 600 R (PE04)600		1997
HONDAXR 600 R (PE04)600		1996
HONDAXR 600 R (PE04)600		1995
HONDAXR 600 R (PE04)600		1994
HONDAXR 600 R (PE04)600		1993
HONDAXR 600 R (PE04)600		1992
HONDAXR 600 R (PE04)600		1991
HONDAXR 600 R (PE04)600		1990
HONDAXR 600 R (PE04)600		1989
HONDAXR 600 R (PE04)600		1988
HONDAXR 600 R (PE04)600		1987
HONDAXR 600 R (PE04)600		1986
HONDAXR 600 R (PE04)600		1985
HONDAXR 650 L (RD06)	650	2015
HONDAXR 650 L (RD06)	650	2014
HONDAXR 650 L (RD06)	650	2013
HONDAXR 650 L (RD06)	650	2012
HONDAXR 650 L (RD06)	650	2011
HONDAXR 650 L (RD06)	650	2010
HONDAXR 650 L (RD06)	650	2009
HONDAXR 650 L (RD06)	650	2008
HONDAXR 650 L (RD06)	650	2007

HONDAXR 650 L (RD06)	650	2006
HONDAXR 650 L (RD06)	650	2005
HONDAXR 650 L (RD06)	650	2004
HONDAXR 650 L (RD06)	650	2003
HONDAXR 650 L (RD06)	650	2002
HONDAXR 650 L (RD06)	650	2001
HONDAXR 650 L (RD06)	650	2000
HONDAXR 650 L (RD06)	650	1999
HONDAXR 650 L (RD06)	650	1998
HONDAXR 650 L (RD06)	650	1997
HONDAXR 650 L (RD06)	650	1996
HONDAXR 650 L (RD06)	650	1995
HONDAXR 650 L (RD06)	650	1994
HONDAXR 650 L (RD06)	650	1993